



Presentation Station Instructions

07/28/14


Parts List




A x1




B x1




C x1




D x1




E x1




F x2




G x1




H x1




J x1




K x1




L x1



M x1




N x4



P x1

Tools Required

- Phillips Screwdriver



15 x1




16 x1



1 x34

M6x12




2 x4

M6x36



3 x14

M4x16



4 x6



5 x4


M3x15



6 x6



7 x6




8 x3



9 x6




10 x4




11 x2



12 x2




13 x2




14 x2


1




2




3




4




5




6




7




8




9




10




11



12



13



14

