


Parts List

Tools Required


- Rubber Mallet

NOTICE:

Leg lengths of leg **E** may be shorter than leg **F**




E x4



F x4


Optional fluted legs for units with cabinet pack



A x1


C x1

B x1




D x4

1




2


Install optional cabinet pack / pullout shelf / electrical assembly after step 1




3




4



5




6



Plastic Cart Cabinet


Pack Instructions

Please consult your cart base unit instructions before starting




1


IMPORTANT: Flip shelf **B**, and lock the 2 locking casters **D** before assembling the unit.




2




3




4



5





6



www.luxorfurn.com
www.hwilson.com




LP + LE Electrical Assembly Instructions

Parts List



Tools Required

- Philips Screwdriver



1

Attach electric outlet **F** to top shelf **A**, secure with L bracket **G** and cable lock **J**. Loop outlet cable **F** through cable lock **J** and the inserts on shelf **A**. Screw L bracket **G** and cable lock **J** onto top shelf **A** with screw **H** and a philips screwdriver.