




The Fletcher-Terry Company

*Quality. Service. Dependability. Value.
Since 1868*

ASSEMBLY INSTRUCTIONS

Fletcher Titan Stand



(Shown with Titan machine mounted)

MyBinding.com
5500 NE Moore Court
Hillsboro, OR 97124
Toll Free: 1-800-944-4573
Local: 503-640-5920

FORM #09-09-10

TABLE OF CONTENTS


<u>TITLE</u>	<u>PAGE</u>
Product Warranty	2
Parts Identification	3
Assembly:	
Step 1: Remove and reposition Material Catcher Plates	4
Step 2: Assemble Lower Cross Beam to Left/Right Vertical Leg Assemblies.....	4
Step 3: Install Roll Stock Material Bar	4
Step 4: Assemble Upper Support Cross Bar:	4
Step 5: Assemble Machine Mounting Plates to top of Vertical Legs Assemblies	5
Step 6: Install Adjustable Jack Screw Knobs: - 80" (2m), 100" (2.5m), 120" (3m) units only.....	5
Step 7: Attach Titan machine onto Stand Assembly.....	6
Step 8: Install Material Catcher Bars and Hammock	6

MyBinding.com
5500 NE Moore Court
Hillsboro, OR 97124
Toll Free: 1-800-944-4573
Local: 503-640-5920


Product Warranty

The Fletcher-Terry Company warrants the product purchased to be free from defects in parts and workmanship for (1) one year from the date of purchase. The Fletcher-Terry Company warrants that it will repair or replace any such defective parts, providing the product has been under normal use and service and the defective part is returned to The Fletcher-Terry Company at the purchaser's expense. The Fletcher-Terry Company must authorize the return in writing. Proof of purchase must be submitted to validate warranty coverage. The warranty is in lieu of all other agreements and warranties expressed or implied. THE FLETCHER-TERRY COMPANY DOES HEREBY EXPRESSLY DISCLAIM ANY WARRANTIES OF MERCHANT ABILITY OR FITNESS FOR A PARTICULAR PURPOSE. The Fletcher-Terry Company does not authorize any company employee or representative to assume for it any other liability than that set forth in this Product Warranty. The Fletcher-Terry Company shall not be liable for any damages or losses, whether incidental or consequential or direct or indirect, arising out of the use or abuse of this product. This Warranty is valid only when product is used with Fletcher consumables and/or replacement parts. In any event, THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS OR ANY OTHER WARRANTY IS LIMITED TO RETURN OF THE PURCHASE PRICE PAID FOR THIS PRODUCT.


Parts Identification




Lower Cross Beam (x1)




Machine Mounting Plate (x2)




Material Catcher Rod (x2)
(Hammock (x1) not pictured)




Upper Cross Bar (x1):
80", 100", 120" bars have
(3) threaded top holes.



Roll Stock Bar (x1)



Material Catcher Support Plate (x2)




Vertical Leg Assembly (x2)




M5 x 10mm Button Head Screw (x8)




M8 x 40mm Hex Head Bolt (x8)



M8 x 60mm Hex Head Bolt (x4)




Tools:
M10/M12 Open End Wrench (x1)
M4 Hex Key Wrench (x1)
M3 Hex Key Wrench (x1)




Adjustable Jack Screw Knob
(x3):
80" (2m), 100" (2.5m), 120"
(3m) units only)


Stand Assembly




Attach Material Catcher Support Plates with M5 Screws (x4) each.
Note position: creates left/right sides.



Attach Lower Cross Beam with
M8 x 40mm Hex Head Bolts
(x2) each end.





Place Roll Stock Bar into nests on
Vertical Leg Assemblies.







Attach Upper Cross Bar with M8 x 40mm
Hex Head Bolts (x2) each side.

Stand Assembly



Stand Assembly



MyBinding.com
 5500 NE Moore Court
 Hillsboro, OR 97124
 Toll Free: 1-800-944-4573
 Local: 503-640-5920