


(W-300A/305A, W-450A/455A, W-600A/605A)

Spare Parts DIAGRAM



MyBinding.com
5500 NE Moore Court
Hillsboro, OR 97124
Toll Free: 1-800-944-4573
Local: 503-640-5920

WH-AUTO SEALER (W-300A / W-305A / W-450A / W-455A / W-600A / W-605A)

No.	Part	Description	
1	A-01	Bracket / Base	
2	A-02	Control Plate / Front Panel	WHA-2
3	A-03	Rear Plate	WHA-3
4	A-04	Cover	
5	A-05	T-Type Bracket	WHA-4
6	A-06A	T-Type 300 / UPPER JAW	
	A-06B	T-Type 450	
	A-06C	T-Type 600	
7	A-07	Spring, Small, Silicon Bracket	WHA-7
8	A-08A	Silicon Bracket 300	
	A-08B	Silicon Bracket 450	
	A-08C	Silicon Bracket 600	
9	A-09A	Silicon 300	SR-
	A-09B	Silicon 450	SR-
	A-09C	Silicon 600	SR-
10	A-10	Spring Bracket	WHA-10
11	A-11	Sucking Plate	WHA-11
12	A-12	Bushing / Pin Washer	WHA-12
13	A-13	Shaft / Hinge Pin	WHA-13
14	A-14	Plate for Teflon Sheet (Clip)	WHA-14
15	A-15	Multi Star Knob	WHA-15
16	A-16A	Teflon Sheet Plate 300 / Front	
	A-16B	Teflon Sheet Plate 450 / Front	
	A-16C	Teflon Sheet Plate 600 / Front	
17	A-17A	Teflon Sheet 300	
	A-17B	Teflon Sheet 450	
	A-17C	Teflon Sheet 600	
18	A-18A	Iron Stick 300	WHA-18a
	A-18B	Iron Stick 450	WHA-18b
	A-18C	Iron Stick 600	WHA-18c
19	A-19A/A-19A5	Heating Wire 300 / 305 (0.8mm)	
	A-19B/A-19B5	Heating Wire 450 / 455	
	A-19C/A-19C5	Heating Wire 600 / 605	
20	A-20A	Flame Retardant 19mm 300	
	A-20B	Flame Retardant 19mm 450	
	A-20C	Flame Retardant 19mm 600	
21	A-21A	Fiber Plate 300	
	A-21B	Fiber Plate 450	
	A-21C	Fiber Plate 600	
22	A-22A	Aluminum Bracket 300	
	A-22B	Aluminum Bracket 450	
	A-22C	Aluminum Bracket 600	
23	A-23	Spring Hook, Mounting	MS-WHA
24	A-24	Spring, Big	
25	A-25	Stop Plate	
26	A-26	Rubber Mat / Rubber Foot	WHA-26
27	E-01	Microswitch / Arm MSW-WHA	MSW-WHA
28	E-02	Power Switch (R), 4P Orange (On/Off)	
29	E-03	Power Switch (G), 6P Green (Manual/Auto)	

No.	Part	Description	
30	E-04	Knob, Red, (WH Knob)	WHA-30
31	E-05	Knob (Y), Yellow	WHA-31
32	E-06	Knob (G), Green	WHA-32
33	E-07	Lamp (R), LED	WHA-33
34	E-08	Lamp (O), LED	WHA-34
35	E-09	Lamp (G), LED	WHA-35
36	E-10	Variable Resistor	WHA-36
37	E-11A	Transformer 300 TF-413	TRNS-
	E-11B	Transformer 450 TF-415	TRNS-
	E-11C	Transformer 600 TF-417	TRNS-
	E-11D	Transformer 305	TRNS-
	E-11E	Transformer 455	TRNS-
	E-11F	Transformer 605 TF-437	TRNS-
38	E-12	Solenoid TF-281	WHA-38
39	E-13	PC Board, w/ 25A Relay	WHA-39
40	E-14	Pin for PC Board	WHA-40
41	E-15	Foot Switch	FSW-WH
42	E-16	Foot Switch Connect	WHA-42
42a		Foot Switch Connect	WHA-42a
43	E-17	Grommet	WHA-43
44	E-18	Power Cord PC-WH	PC-WH
45	E-19	Fuse Holder	WHA-45
46	E-20	Fuse (1A)	WHA-46
47	E-21B	Fuse (10A) 300 / 450	
47a	E-21C	Fuse (15A) 600	
48	S-01	Nut 1/4	
49	S-02	Washer 1/4 x 1 x 16	
50	S-03	Hex Cap Screw 5/16 for #8	WHA-50
51	S-04	Washer	WHA-51
52	S-05	Hex Cap Screw 1/4x1 for #10	WHA-52
53	S-06	Screw 4x25	
54	S-07	Screw #54 for Shaft/Hinge Pin (not shown)	
55	S-08	Screw 1/4x3 1/4 for #11	WHA-55
56	S-09	Screw 4x8	
57	S-10	Bushing (R)	WHA-57
58	S-11	Solderless Terminal 2-8	
59	S-12	Bushing (BK), Convex	WHA-59
60	S-13	Washer 3/16	
61	S-14	Screw 3/16x1/2	
62	S-15	Screw 5x8	
63	S-16	Screw 5x15	
64	S-17	Washer 3/8x2x24 for #5	WHA-64
65	S-18	Spring Washer 3/8 for #5	WHA-65
66	S-19	Hex Cap Screw 3/8x3/4 for #5	WHA-66
67		Handle	
68			
69		Inner Box	
69a		Outer Box	

MyBinding.com
 5500 NE Moore Court
 Hillsboro, OR 97124
 Toll Free: 1-800-944-4573
 Local: 503-640-5920