


Parts List

Tools Required


- Rubber Mallet

NOTICE:

Leg lengths of leg **E** may be shorter than leg **F**




E x4



F x4


Optional fluted legs for units with cabinet pack



A x1


C x1

B x1




D x4

1




2


Install optional cabinet pack / pullout shelf / locking drawer assembly after step 1




3




4




5



6









Parts List



Tools Required

- Rubber Mallet

- 1** **IMPORTANT:** Flip shelf **B**, and lock the 2 locking casters **D** before assembling the unit.




www.luxorfurn.com
www.hwilson.com

Electric Assembly Instructions



Number of outlets
may vary.

Parts List



Tools Required

- Screwdriver



1

Push screw **C** through electric outlet **A**. Make sure the electric outlet **A** and cord wrap **B** align with the mounting surface screw holes. Push screw **C** through cord wrap **B** and the mounting surface screw holes. Use wing nut **D** and screwdriver to fasten.